



Description

The Pneumatic Piezometer is designed for accurately measuring pore water pressures in fully or partially saturated soil and rock.

The Pneumatic Piezometer tip comprises an integral porous element with a high quality diaphragm transducer, installed either down a

borehole, by burying in fill or by pushing into shallow depths in soft soil.

Twin nylon tubes in a polythene sheath can connect the transducer to a terminal panel or to the portable readout unit directly.

Features

- Low volume change
- · Can be installed in horizontal and upholes
- Pneumatic tubing is strong and flexible and can be installed in lengths of up to 500m
- All piezometer components corrosion proof

Benefits

- Small, accurate and reliable design
- Fast response
- Ideal for underground works
- Suitable for flow or no-flow operation
- Level of tubing in relation to readout is not critical



Comprehensive information about this product and our full range is available at www.soilinstruments.com If you would like to speak with someone directly please call +44 (0)1825 765044 or email sales@soilinstruments.com

PRECISELY MEASURED

Operation

The piezometer is buried in fill, suspended in a borehole or pushed into soil.

Twin tubes connect the transducer within the piezometer tip to either a pneumatic terminal panel or a readout unit. When pore water pressure is exerted on the diaphragm, reverse pressure is applied until pressure equilibrium is reached, then the readout unit displays the reading.

The readout displays engineering-based units. Readings can be taken up to 500m from the tip.


Applications

Piezometers are used in geotechnical, environmental, and hydrological applications. They can be installed in boreholes and placed in fill materials or open wells to measure water levels or pore water pressures to enable engineers to verify design assumptions and control placement of fill.

Typical applications include:

- For environmental management including landfill sites
- Monitoring of aquifers
- Monitor tidal effects on coastal soils
- Dams
- Embankments
- Potential landslide sites
- Dewatering excavations
- Tailings lagoons
- Pumping tests
- Monitor seepage
- · Control placement of fill





THE TECHNICAL RATING FOR THIS PRODUCT:

As the correct installation of any monitoring sensor or system is vital to maximise performance and accuracy, Soil Instruments makes the following recommendations, for the skill level of the installation contractor.

ADDITIONAL SUPPORT

We offer installation and monitoring services to support this system. For more information please email: sales@soilinstruments.com or call: +44 (0) 1825 765044

ADVANCED







The installer is trained and experienced in the installation of this type of instrument or systems, and is ideally a specialist Instrumentation and Monitoring contractor.

INTERMEDIATE



The installer already has previous experience and/or training in the installation of this instrument or system.

BASIC



As a minimum the installer has read and fully comprehends the manual, and if possible has observed these instruments or systems being installed by others.

Specifications Sensor +30 to +1000kPa Range Material Brass/PVC ±2.0% full scale Accuracy Outside Diameter 38mm Filter HAE Ceramic LAE Ceramic Type Porosity 1 Micron 60 Micron 48mm Length Diameter 38mm Tubing Overall diameter 9mm Internal tube outside diameter 3.2mm Construction Twin nylon 11 tubes, sheathed in LDP (low density polyethylene) Weight 5.1kg/100m Maximum length advisable 500m Readout Unit Gauge readout Туре

0-20 | 0-40 | 0-60 | 0-100 | 0-200

0.5% full scale

0.5 | 1 | 1 | 2 | 5

-10 to +60°C

IP65

_			
Ord	erina	Inform	ation

Range (m/H2O)

Resolution (m/H2O)

Operating temperature

Accuracy

IP rating

For use with $\frac{1}{8}$ inch twin tube W6-2.1, Enots connections

W3-1.1 With LAE ceramic filter; low resistance to air entry (60 Micron)
W3-1.2 With HAE ceramic filter; high resistance to air entry (1 Micron)

Piezometer Tubing and Tube Fittings

riezonneter rubing a	
W6-2.1	Twin 1⁄8 inch tubing; round tube, 9mm outside diamteter, price per metre
W6-3.1	Straight coupling; Enots % inch, in-line tubing connections, 2No. required per twin tube connection
W6-3.2	Spare nut and olive; Enots 1/8 inch
W6-3.23	Spare nut; Wade ¾i nch
W6-3.24	Spare olive; Wade ⅓ inch
W6-3.3	Quick release coupling set; % inch, includes one male and one female quick release coupling, Wade olives, one set required per instrument twin tube
CA-4.2	Coloured adhesive tapes; set of 10No.
W6-3.18	Connection charge per piezometer tip to twin tube
W3-4.8	Tube cutter

Terminal Equipment

For % inch twin tube W6-2.1

C9-3.7	Lockable stopcock cover
W3-3.1	Lockable stopcock cover terminal unit - 1No. sensor
W3-3.2	Lockable stopcock cover terminal unit - 2No. sensors
W3-3.3	Lockable stopcock cover terminal unit - 3No. sensors
W3-3.4	Terminal panel - 5No. sensors
W3-3.5	Terminal panel - 10No. sensors
W3-3.6.6	Switched terminal panel; for 6No. sensors
W3-3.6.10	Switched terminal panel; for 10No. sensors
W3-3.6.15	Switched terminal panel; for 15No. sensors
W3-3.6.20	Switched terminal panel; for 20No. sensors
W6-5.1	Terminal cabinet - for up to 6No. sensors terminal panel, 600 x 600 x 250mm
W6-5.2	Terminal cabinet - for up to 10No. sensors terminal panel, 800 x 600 x 250mm
W6-5.3	Terminal cabinet - for up to 15No. sensors terminal panel, 1000 x 800 x 250mm
W6-5.4	Terminal cabinet - for up to 20No. sensors terminal panel, $1200 \times 800 \times 400$ mm

Installation Accessories	
W6-8.1	Punner; to compact material in borehole, for use with W6-8.2 or W1-2.7
W1-2.7	Galvanised standpipe tubing; mild steel, galvanised, includes coupling, 1 metre length, ¾ inch nominal bore, ¾ inch BSP thread
W6-8.2	Galvanised standpipe tubing; mild steel, galvanised, includes coupling, 3metre length, ¾ inch nominal bore, ¾ inch BSP thread
W3-4.3	Placing adaptor; for use with W6-8.2 or W1-2.7
W3-4.8	Tube cutter
CA-4.2	Coloured adhesive tapes; set of 10No.
W2-4.11	Standard Tool Kit; tool box includes knife, 3m measuring tape, 8 inch adjustable spanner, 2No. flat screwdrivers, combination pliers, ball hammer, 6No. English spanners 1/4 to 1 inch
W6-1.2	Bentonite powder; 25kg bag
W6-1.3	Filter sand; 25kg bag
W6-1.1	Bentonite pellet; 25kg bag
	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate
Includes readout, pneuma RO-2-GPR-1	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5 Spares & Accessories RO-2-GPR-15	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5 Spares & Accessories RO-2-GPR-15 RO-2-GPR-16	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water Spare pneumatic flylead
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5 Spares & Accessories RO-2-GPR-15 RO-2-GPR-16 RO-2-GPR-17	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water Spare pneumatic flylead Spare pneumatic flylead
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5 Spares & Accessories RO-2-GPR-15 RO-2-GPR-16 RO-2-GPR-17	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water Spare pressure range 0 - 200 metres head of water Spare pneumatic flylead Spare pump adaptor
9	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water Spare pressure range 0 - 200 metres head of water Spare pneumatic flylead Spare pump adaptor
Includes readout, pneuma RO-2-GPR-1 RO-2-GPR-2 RO-2-GPR-3 RO-2-GPR-4 RO-2-GPR-5 Spares & Accessories RO-2-GPR-15 RO-2-GPR-16 RO-2-GPR-17 RO-2-GPR-18	tic flylead (with quick release couplings), recharge flylead, pump adapter, manual and calibration certificate Pressure range 0 - 20 metres head of water Pressure range 0 - 40 metres head of water Pressure range 0 - 60 metres head of water Pressure range 0 - 100 metres head of water Pressure range 0 - 200 metres head of water Spare pressure range 0 - 200 metres head of water Spare pneumatic flylead Spare pump adaptor



